

Credit Card Terminal Troubleshooting



Credit Card Terminal Not Responding:


First, try restarting the credit card terminal.

Press and hold the – (minus) and Clear buttons until the terminal restarts.

Once you see the Goodwill logo try another transaction.

Credit Card Terminal STILL Not Responding:

Shucks! Only thing to do now is restart the Register.

Press the  (Windows Key, lower left on keyboard) and then press Restart on the menu.

If a message comes up asking to force close a program just click Ok.

Once the register restarts, you'll be all set!

Windows Key



Start Menu

